



**Ozi Tatami**  
PO Box 32  
Coffs Harbour 2450  
NSW Australia  
Ph: 0423 076 118  
Fax: 02 6652 5802

## Ozi Tatami Cutting Stand Instructions

Before starting assembly, please check that the kit contains the following:

1. Hardwood post 900mm high
2. 4 x legs (Marked A,B,C, and D) with rubber feet.
3. 12 x 5mm hex drive galvanised screws
4. 2 x 22mm  $\varnothing$  Tassie Oak pegs.

To complete assembly you will also need a 5mm hex key or drill bit driver.

1. Place the leg marked 'A' against the 'A' on the post with the countersunk screw holes facing outwards.
2. Align the pre-drilled holes and screw the leg to the post using 3 screws with the 5mm hex driver. Only tighten until firm. Do not over tighten or the screw will strip the hole and become loose.
3. Repeat for legs B,C and D until it looks like the following pictures:



Paint, lacquer or stain to your heart's content and

**START CUTTING!**